

STEALTH FIT GUIDE

GUIDE D'INSTALLATION STEALTH VEHICULOS APTOS PARA STEALTH

January 1st., 2004

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
ACURA				
CL	97-02			
Integra 3dr.	94-01	x	x	x
Integra 4dr.	94-01			
Legend Sedan	91-95			
Legend Sedan	86-90	x	x	x
MDX	01			
RL	01-02			
RL	96-00			
RSX	02	x	x	x
TL	99-02			
TL	96-98			
AUDI				
200 Sedan	89-91			
90 Sedan	88-95			
A4 Sedan	96-01			
A6 Sedan	98-01			
A6 Sedan	95-97			
A6 Wagon	96-99			
A8 Sedan	97-01	x	x	x
Allroad	01	x	x	x
S4 Wagon	01	x	x	x
BMW				
3 Series Conv	99-02			
3 Series Conv	92-98			
3 Series Coupe	00-01			
3 Series Coupe	92-99			
3 Series Sedan	99-02			
3 Series Sedan	92-98			
3 Series Wagon	00-01	x	x	x
318 ti 2dr Hbk.	96-98	x	x	x
318 ti 2dr Hbk.	92-94			
5 Series Sedan	97-01			
5 Series Sedan	89-95			
5 Series Wagon	99-01	x	x	x
5 Series Wagon	92-95	x	x	x
7 Series Sedan	95-01			
8 Series Coupe	91-97			
M3 Coupe	99			
M3 Coupe	95-98			
M3 Sedan	97-98			
X-5	00-02	x	x	x
Z3 Conv	97-01			
Z3 Coupe	99-01	x	x	x
BUICK				
Century	97-01			
Le Sabre	00-01			
Vans, Full Size	79-01			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
Le Sabre	92-99			
Park Avenue	97-01		x	x
Park Avenue	91-96		x	x
Regal 2dr	88-95			
Regal 4dr	97-01			
Regal 4dr	88-95			
Rendez-Vous	02		x	x
Skylark 2dr	92-95			
Skylark 4dr	92-97			
CADILLAC				
Catera	97-01			
De Ville	00-01			
Eldorado	92-00			
Escalade	99-01		x	x
Seville	98-01		x	x
Seville	92-97			
CHEVROLET				
Astro	89-01	x	x	x
Beretta	87-96		x	x
Blazer S-10 2dr	95-02	x	x	x
Blazer S-10 4dr	95-02	x	x	x
Camaro Conv	01	x	x	x
Camaro Coupe	01	x	x	x
Camaro Coupe	93-00	x	x	x
Cavalier Coupe	95-02			
Cavalier Coupe	89-94			
Cavalier Sedan	95-02			
Cavalier Sedan	88-94			
Corsica	87-95	x	x	x
Express Van	96-00		x	x
Impala	00-01	x	x	x
Lumina Sedan	95-99			
Malibu 4dr	97-02			
Metro 4dr	98-00			
Monte Carlo	00-02			
Monte Carlo	95-99			
Nova	86-88			
Prizm	98-02			
Suburban	00-02	x	x	x
Suburban	92-99	x	x	x
Tahoe 2dr	92-99	x	x	x
Tahoe 4dr	00-02	x	x	x
Tahoe 4dr	95-99	x	x	x
Trailblazer	02	x	x	x
CHRYSLER				
300M	98-01			
Cirrus	96-00			
Windstar	95-98			
ZX2	97-00			
Concorde	98-01	x	x	x
Concorde	93-97			
Le Baron Conv	87-93	x	x	x

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
Le Baron Coupe	87-93	x	x	x
Le Baron Sedan	89-94	x	x	x
LHS	98-01			
LHS	93-97			
New Yorker	94-97	x	x	x
New Yorker	88-93	x	x	x
PT Cruiser	01-02			
Sebring Conv	01		x	x
Sebring Conv	95-99			
Sebring Coupe	01			
Sebring Coupe	95-00			
Sebring Sedan	01			
Town & Country	01-02	x	x	x
Town & Country	96-00	x	x	x
Town & Country	92-95			
Voyager	01-02	x	x	x
DAEWOO				
Lanos 3dr	98-01	x	x	x
Lanos Sedan	98-01			
Leganza	98-01			
Nubira Sedan	98-01			
Nubira Wagon	98-01			
DODGE				
Avenger	95-99			
Caravan	01-02	x	x	x
Caravan	96-00	x	x	x
Caravan	92-95			
Caravan	84-91			
Durango	98-02			
Grand Caravan	01-02	x	x	x
Grand Caravan	96-00	x	x	x
Grand Caravan	92-95			
Intrepid	98-01			
Intrepid	93-97			
Lancer 4dr Liftback	85-89			
Neon 2dr	95-99			
Neon 4dr	00-02			
Neon 4dr	95-99			
Shadow 2dr	87-94	x	x	x
Shadow 4 dr	87-94	x	x	x
Spirit Sedan	89-94	x	x	x
Stealth	92-96	x	x	x
Stratus Coupe	01			
Stratus Sedan	01			
Stratus Sedan	96-00	x	x	x
Passport	98-01	x	x	x
Prelude	97-01			
Prelude	92-96			
Prelude	89-91	x	x	x
Prelude	83-87			
S2000 Conv	01	x	x	x

STEALTH FIT GUIDE

GUIDE D'INSTALLATION STEALTH VEHICULOS APTOS PARA STEALTH

January 1st., 2004

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
EAGLE				
Talon	95-99	x	x	x
Talon	89-94	x	x	x
Vision	93-97			
FORD				
Aerostar	86-97			
Aspire	94-97			
Contour	95-00			
Crown Victoria	98-01			
Escape	01			
Escort 2dr	91-96			
Escort 2dr	81-90			
Escort 4dr	91-96			
Escort 4dr Sedan	97-99			
Escort 4dr Sedan	92-96			
Escort 4dr Sedan	81-90			
Escort Wagon	97-99			
Escort Wagon	91-96			
Excursion	00-02	x	x	x
Expedition	97-01			
Explorer 2dr	98-00			
Explorer 2dr	91-97			
Explorer 4dr	02			
Explorer 4dr	98-01			
Explorer 4dr	91-97			
Explorer Sport	01-02			
Focus 3dr, ZX3	00-02			
Focus 5dr, ZX5	02			
Focus Sedan	00-02			
Focus Wagon	00-01			
Mustang 2dr Hbk.	87-93	x	x	x
Mustang Conv	99-01			
Mustang Conv	94-98			
Mustang Coupe	99-01			
Mustang Coupe	94-98			
Probe	93-97			
Probe	88-92			
Taurus Sedan	00-02			
Taurus Sedan	96-99			
Taurus Sedan	86-95			
Taurus Wagon	00-01			
Taurus Wagon	96-99			
Taurus Wagon	86-95			
Tempo 4dr	84-94			
Thunderbird 2dr	89-97			
Vans/Club Wagons	79-01	x	x	x
Windstar	99-01		x	x
GEO				
Metro 2dr	95-97			
Metro 2dr	89-94			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
Metro 4dr Sedan	95-97			
Prizm Sedan	93-97		x	x
Storm Coupe	90-93	x	x	x
GMC				
Envoy	98-00	x	x	x
Jimmy S-15 2dr	95-00	x	x	x
Jimmy S-15 4dr	95-01	x	x	x
Safari	89-01	x	x	x
Savannah Van	96-00	x	x	x
Suburban	92-99	x	x	x
Yukon 2dr	92-99		x	x
Yukon 4dr	00-02	x	x	x
Yukon 4dr	95-99		x	x
Yukon XL	00-01	x	x	x
HONDA				
Accord 2dr Hbk.	86-89	x	x	x
Accord Coupe	98-01	x	x	x
Accord Coupe	94-97			
Accord Coupe	90-93			
Accord Coupe	83-89			
Accord Sedan	98-01			
Accord Sedan	94-97			
Accord Sedan	90-93			
Accord Sedan	86-89			
Accord Sedan	79-85			
Accord Wagon	94-97			
Accord Wagon	91-93			
Civic 2dr Hbk.	96-99	x	x	x
Civic 2dr Hbk.	92-95			
Civic 2dr Hbk.	88-91			
Civic Coupe	01			
Civic Coupe	96-00			
Civic Coupe	92-95			
Civic Sedan	01			
Civic Sedan	96-00			
Civic Sedan	92-95			
Civic Sedan	88-91			
Civic Sedan	84-87			
Civic CRX	88-91	x	x	x
CR-V	02	x	x	x
Insight	01	x	x	x
Odyssey	99-01	x	x	x
Protégé	95-98			
Protégé 5	02			
Tribute	01-02			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
HYUNDAI				
Accent 2dr	00-02			
Accent 4dr	00-02			
Elantra 5dr	01-02			
Elantra Sedan	01-02			
Elantra Sedan	96-00			
Elantra Sedan	92-95			
Elantra Wagon	96-00			
Santa Fe	01-02			
Sonata	02			
Sonata	99-01			
Sonata	95-98			
Sonata	89-94			
Tiburon	97-01			
XG300	01			
INFINITY				
G20	99-02			
G20	91-96			
I30	00-01			
I30	96-99			
I35	02			
J30	92-98			
Q45	02			
Q45	97-01			
Q45	90-96	x	x	x
QX4	00-02			
QX4	97-99			
ISUZU				
Rodeo	98-01	x	x	x
JAGUAR				
XJ6 Sedan	87-94			
XK8 Conv	97-01	x	x	x
JEEP				
Cherokee	90-99			
Cherokee Sport	00-01			
Grand Cherokee	99-02			
Grand Cherokee	93-98			
Liberty	02	x	x	x

This list is intended as a guide only. As models specifications and availability may vary, we suggest that you contact your vehicle's manufacturer should you wish install on a non-recommended vehicle or a vehicle that is not yet listed in this guide. Consult your Stealth owners manual for details installations instruction. Please consult your vehicle's owners manual prior to rack installation for specific manufacturer guidelines. Please note that installations on a non-recommended or non-listed vehicles are the sole risk and responsibility of the user. Norco Products Ltd. will not be held responsible for any damages, losses or injuries incurred from improper, non-recommended installation or installation on vehicles not contained in this list.

STEALTH FIT GUIDE

GUIDE D'INSTALLATION STEALTH VEHICULOS APTOS PARA STEALTH

January 1st., 2004

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
KIA				
Rio Sedan	00-02			
Rio Cinco Wagon	02	x	x	x
Sedona	02			
Sephia Sedan	98-01			
Spectra 5dr	00-02	x	x	x
Spectra Sedan	02			
LAND ROVER				
Range Rover SE	95-01			
LEXUS				
ES300	02			
ES300	97-01			
GS300	98-02			
GS300	93-96	x	x	x
GS400	98-00			
GS430	01-02	x	x	x
IS300	01-02			
LS400	95-00			
LS430	01-02			
LX450	96-97			
LX470	00-01			
RX300	98-02			
SC300	92-99			
SC400	92-99			
LINCOLN				
Continental	98-01			
Continental	88-97			
LS	00	x	x	x
Mark VIII	93-98			
Navigator	98-00			
Town Car 4dr	98-01			
MAZDA				
626 2dr	83-87	x	x	x
626 4dr	98-02	x	x	x
626 4dr	93-97	x	x	x
626 4dr	83-87	x	x	x
Miata Conv	98-01	x	x	x
Miata Coupe	91-97	x	x	x
Millenia	94-01	x	x	x
MPV	00-01			
MPV	89-98			
MX-3	92-95			
MX-6	93-96			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
MERCEDES				
MX-6	88-92			
Navajo	91-94			
Protégé	99-02			
MERCEDES				
190E	84-93			
300 SD	81-91			
C-Class Sedan	01-02			
C-Class Sedan	94-98			
CL600	98-99			
E320 Sedan	96-02			
E320 Wagon	98-02	x	x	x
E320 Wagon	94-00	x	x	x
M-Class	98-01	x	x	x
S-Class Sedan	99-02			
SL500 Coupe	96-99	x	x	x
SLK Coupe	02			
MERCURY				
Cougar 2dr	99			
Cougar 2dr	89-97			
Grand Marquis	98-00			
Grand Marquis 2 dr	98-00			
Mountaineer	97-00			
Mystique	95-00	x	x	x
Sable Sedan	00			
Sable Sedan	96-99			
Sable Wagon	96-99			
Sable Wagon	86-95			
Topaz 4dr	84-94			
Tracer Sedan	97-99			
Tracer Sedan	91-96			
Tracer Wagon	97-99			
Tracer Wagon	91-96			
Villager	99-00			
Villager	93-98			
MITSUBISHI				
Diamante Sean	97-99			
Eclipse	00-02	x	x	x
Eclipse	90-94	x	x	x
Expo	92-96			
Galant	99-02			
Galant	89-93			
Lancer	02			
Lancer w/ Spoiler	02			
Mirage 2dr	97-00			
Mirage 4dr	97-00			
Montero Sport	97-02			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
NISSAN				
200 SX	95-98			
120 SX Coupe	93-95			
300 ZX	84-89	x	x	x
Altima	02			
Altima	98-01			
Altima	93-97			
Maxima Sedan	00-02			
Maxima Sedan	95-99			
Pathfinder 4dr	99-02			
Pathfinder 4dr	96-99			
Pathfinder 4dr	90-95			
Quest	99-02			
Quest	93-98			
Sentra 2dr	91-94			
Sentra 4dr	00-02		x	x
Sentra 4dr	95-99			
Sentra 4dr	91-94			
Stanza Sedan	90-92			
Xterra	99-02	x	x	x
OLDSMOBILE				
Alero 2dr	99-00			
Alero 4dr	99-01			
Aurora	01			
Bravada	95-01			
Delta 88	86-89			
Intrigue	98-01			
Silhouette	97-01			
PLYMOUTH				
Breeze	96-00	x	x	x
Grand Voyager	96-00	x	x	x
Grand Voyager	92-95	x	x	x
Neon 2dr	95-99			
Neon 4dr	00-01			
Neon 4dr	95-99			
Voyager	96-00	x	x	x
Voyager	92-95			
Voyager	84-91			
PONTIAC				
Aztek	01-02	x	x	x
Bonneville	00-02			
Bonneville	92-99			
Firbird Coupe	93-00	x	x	x
Grand Am 2dr	99-02	x	x	x
Grand Am 2dr	92-98	x	x	x
Grand Am 2dr	85-91	x	x	x
Grand Am 4dr	99-02			
Grand Am 4dr	92-98			
Grand Am 4dr	85-91			
Grand Prix 2dr	97-02	x	x	x

Cette liste doit être interprétée comme un guide seulement. Comme les fiches techniques des modèles peuvent varier, nous vous suggérons de contacter le fabricant de votre véhicule si vous souhaitez installer un support sur un véhicule non recommandé ou absent de ce guide. Consultez votre manuel de l'utilisateur Stealth pour plus de détails à propos de l'installation. Consultez également le manuel du propriétaire de votre véhicule avant d'installer un support afin de suivre les recommandations du fabricant. Prenez note que l'installation d'un support sur un véhicule non recommandé ou non listé par Norco est aux risques et à la responsabilité de l'utilisateur. Norco Products LTD ne sera pas tenu responsable des dommages, pertes et/ou blessures occasionnés par une mauvaise installation, une installation non recommandée ou une installation sur un véhicule absent de cette liste.

STEALTH FIT GUIDE

GUIDE D'INSTALLATION STEALTH VEHICULOS APTOS PARA STEALTH

January 1st., 2004

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
Grand Prix 2dr	88-96			
Grand Prix 4dr	97-02	x	x	x
Grand Prix 4dr	90-96			
Le Mans 2dr Hbk.	88-93			
Montana	99-02			
Sunbird 4dr	85-94			
Sunfire 2dr	95-02	x	x	x
Sunfire 4dr	95-01			
Trans Am Coupe	93-00	x	x	x
SAAB				
9-3 5dr	99-00			
9-3 Conv	99-01			
9-5 4dr	99-00			
9-5 Wagon	99-00	x	x	x
900 3dr	94-98			
900 5dr	95-98			
900 5dr	79-93			
900 Conv	94-98			
9000	90-97			
SATURN				
L Series Sedan	00-02			
LW Wagon	00-02			
SC 2dr Coupe	97-99			
SC 2dr Coupe	91-96			
SC 3dr Coupe	01-02	x	x	x
SC 3dr Coupe	99-00			
SL Sedan	96-02			
SL Sedan	91-95			
SW Wagon	96-01			
SW Wagon	93-95	x	x	x
Vue	02			
SUBARU				
2dr	85-89			
4dr	85-89			
Forester	98-02			
Impreza Coupe	95-99			
Impreza Sedan	02			
Impreza Sedan	93-00	x	x	x
Impreza Wagon	02			
Impreza Wagon	93-01	x	x	x
Legacy Sedan	00-02			
Legacy Sedan	95-99			
Legacy Wagon	00-02			
Outback Sedan	00-02			
Outback Wagon	00-02			
Outback Wagon	96-99			
Outback Sport	02			
Outback Sport	98-01	x	x	x
Wagon	85-94			
WRX Sedan	02			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
SUZUKI				
Esteem Sedan	97-01			
Esteem Wagon	98-02			
Swift 3dr	95-01			
X-90	98			
TOYOTA				
4-Runner	96-02			
4-Runner	90-95	x	x	x
Avalon	00-01			
Avalon	95-99			
Camry Sedan	02			
Camry Sedan	97-01			
Camry Sedan	92-96			
Camry Sedan	87-91	x	x	x
Celica Conv	94-98			
Celica Conv	90-93			
Celica Coupe	00-02	x	x	x
Celica Coupe	94-98			
Celica Coupe	90-93			
Corolla Sedan	98-01			
Corolla Sedan	93-97			
Echo 2dr	00-02			
Echo 4dr	00-02			
Highlander	01-02			
Land Cruiser	98-01			
Land Cruiser	91-97			
Matrix	02			
Paseo	95-95			
Previa	90-97			
Prius	01-02			
Sequoia	01-02			
Sienna	98-02			
Solara	99-01	x	x	x
Terrel 2dr	95-98			
Terrel 2dr	91-94			
Terrel 2dr	87-90			
Terrel 3dr Liftback	87-90			
Terrel 4dr	95-98			
Terrel Wagon	83-88			

X = NO FIT	STEALTH RACK			
	YEAR	+2	+3	+4
VOLKSWAGEN				
Beetle, New	98-02	x	x	x
Cabrio	01			
Cabriolet	94-99			
Eurovan	93-99			
Golf 4dr	99-02			
Golf 4.dr	93-98			
Golf 4dr	85-92			
Golf/GTI 2dr	99-01			
Golf/GTI 2dr	93-98			
Jetta 2dr	99-02			
Jetta 2dr	85-92			
Jetta 4dr	99-02			
Jetta 4dr	93-98			
Jetta 4dr	85-92			
Jetta Wagon	01			
Passat Sedan	98-02			
Passat Sedan	90-97			
Passat Wagon	98-01			
Passat Wagon	90-97			
VOLVO				
240/260 2dr Sedan	79-93			
240/260 4dr Sedan	79-93			
240/260 Wagon	79-93			
740 Sedan	91-97			
740/760 Sedan	83-90			
740/760 Wagon	83-90			
850 Sedan	93-97			
960 Sedan	91-97			
960 Wagon	91-97			
C70	98-01			
CrossCountry	01			
CrossCountry	98-00	x	x	x
S40	99-01			
S60	02			
S70	98-00			
S80	99-02	x	x	x
S90	98			
V40	99-01			
V70	01-02	x	x	x
V70	98-00	x	x	x
V90	98			

Esta lista es solamente una guía. Como las especificaciones de los modelos varían, o si usted desea instalar un portabicicletas Stealth en un vehículo no incluido aún en esta lista, le sugerimos que contacte al fabricante de su vehículo. Consulte su Manual del Usuario para instrucciones detalladas de instalación. Por favor consulte también el manual de su vehículo antes de instalar el portabicicletas para que siga las instrucciones del fabricante. Tenga en cuenta que la instalación del portabicicletas en un vehículo no recomendado o no incluido en esta lista será únicamente bajo el riesgo y la responsabilidad del usuario. Norco Products Ltd. no tendrá ninguna responsabilidad por daños, pérdidas o lesiones causadas por instalaciones inapropiadas en vehículos no recomendados o no incluidos en esta lista.